
Sonoma 76" Bench (071)



ASSEMBLY INSTRUCTIONS

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE BEGINNING.
Carefully remove contents from box. Make sure that all parts and hardware are included using the Parts List below.

Tools Required: 4mm Allen Wrench (included); #2 Phillips Head Screwdriver;




WARRANTY QUESTIONS OR COMMENTS PLEASE CALL TOLL FREE AT 1-800-809-3114

2

ATTACH FIRST STRETCHER TO LEG ASSEMBLIES

ATTACH SECOND STRETCH-ER

Attach stretcher (without the hanger bolt), with Counter-bores facing up, to (2) leg assemblies using (4) 80 mm Hex



Lags thru counterbored holes in Leg Assembly into pilot holes in both sides of Stretcher. Attach second stretcher (with Hanger Bolt) by inserting the hanger bolt into threaded insert on leg assembly and turning clockwise until snug. Continue turning until counter-bores are facing up.



4


ATTACH THIRD LEG ASSEMBLY

5 ATTACH BASE TO SEAT ASSEMBLY

Attach Third leg Assembly to second stretcher with (2) 80mm Hex Lags as shown.



Align middle leg with mid cleat on Seat. Center the outer legs and secure using (24) 1-3/4" Phillips Head Screws.




6

ATTACH ANGLE BRACES

SECURE END CAPS

Slide Angle Braces under the notch in the cleats in the Seat Assembly. Turn until aligned with stretchers. Secure using (8) 80mm lags thru counter-bores in Stretchers into pilot holes in Angle Braces.



Insert End Caps into threaded insert in Leg Assembly. Turn clockwise until snug. Continue turning until in line with the Stretcher. Secure end caps into legs with (2) 1-3/4" Phillips Head Screws.